



01 0101  
KISA PASO ANAHTAR  
KLEMENSLİ

PUSH-PULL SWITCH  
SHORT

01 0201  
UZUN PASO ANAHTAR  
KLEMENSLİ

PUSH-PULL SWITCH  
LONG



01 0109  
KISA PASO ANAHTAR  
TERMINALLİ

PUSH-PULL SWITCH  
SHORT 6,3 TERMINAL

01 0209  
UZUN PASO ANAHTAR  
TERMINALLİ

PUSH -PULL SWITCH  
LONG 6,3 TERMINAL



01 0103  
KISA PASO ANAHTAR  
KLEMENSLİ  
BÜYÜK DÜĞMELİ

PUSH-PULL SWITCH  
SHORT BIG BUTTON

01 0203  
UZUN PASO ANAHTAR  
KLEMENSLİ  
BÜYÜK DÜĞMELİ

PUSH-PULL SWITCH  
LONG BIG BUTTON




01 0110  
KISA PASO ANAHTAR  
TERMINALLİ  
BÜYÜK DÜĞMELİ

PUSH-PULL SWITCH  
SHORT BIG BUTTON 6,3 TERMINAL

01 0210  
UZUN PASO ANAHTAR  
TERMINALLİ  
BÜYÜK DÜĞMELİ

PUSH-PULL SWITCH  
LONG BIG BUTTON 6,3 TERMINAL




01 0102  
YM. KISA PASO ANAHTAR  
KLEMENSLİ

PUSH-PULL SWITCH  
SHORT

01 0202  
YM. UZUN PASO ANAHTAR  
KLEMENSLİ

PUSH-PULL SWITCH  
LONG



01 0111  
YM. KISA PASO ANAHTAR  
GÜMÜŞ KONTAKLI

PUSH-PULL SWITCH SHORT  
WITH SILVERED CONTACTS  
CORROSION - PROOF TYPE

01 0211  
YM. UZUN PASO ANAHTAR  
GÜMÜŞ KONTAKLI

PUSH-PULL SWITCH LONG  
WITH SILVERED CONTACTS  
CORROSION - PROOF TYPE



01 0104  
YM. KISA PASO ANAHTAR  
KLEMENSLİ  
BÜYÜK DÜĞMELİ

PUSH-PULL SWITCH SHORT  
BIG BUTTON

01 0204  
YM. UZUN PASO ANAHTAR  
KLEMENSLİ  
BÜYÜK DÜĞMELİ

PUSH-PULL SWITCH LONG  
BIG BUTTON



01 0107  
IŞIKLI KISA PASO  
ANAHTAR (AMPULSÜZ)  
4 RENK İKAZLI

PUSH-PULL SWITCH  
WITH WARNING LIGHT  
(WITHOUT BULB)  
4 COLOUR INDICATORS

01 0108  
IŞIKLI KISA PASO  
ANAHTAR (12V AMPULLÜ)  
4 RENK İKAZLI

PUSH-PULL SWITCH  
WITH WARNING LIGHT  
(WITH 12V BULB)  
4 COLOUR INDICATORS




01 0301  
SAĞ SOL ANAHTAR

CHANGEOVER SWITCH



01 0401  
ÇIT ÇIT ANAHTAR

ON/OFF TOGGLE SWITCH




01 0402  
SAĞ SOL ÇIT ÇIT ANAHTAR

ON/OFF/ON TOGGLE SWITCH




01 0501  
ÇİFT ÇEKME Lİ ANAHTAR

HEADLIGHT PUSH-PULL SWITCH



01 0502  
ÇİFT ÇEKME Lİ ANAHTAR  
20 A SİĞORTALI

HEADLIGHT PUSH-PULL SWITCH  
(20 A FUSE)



03 0101  
PLASTİK BUTON  
KLEMENSLİ

PUSH-BUTTON SWITCH

● 03 0105 ○ 03 0106



03 0103  
PLASTİK BUTON  
KLEMENSLİ  
ÜST KORUMA ŞAPKALI

PUSH-BUTTON SWITCH  
WITHDAMP - PROOFCOVER

● 03 0111



03 0104  
PLASTİK BUTON  
KLEMENSLİ  
ÜST VE ALT KORUMA ŞAPKALI

PUSH-BUTTON SWITCH  
WITHDAMP - PROOFCOVER  
WHOLE BODY



03 0102  
PLASTİK BUTON  
TERMİNAL Lİ

PUSH BUTTON SWITCH  
6,3mm TERMINAL

● 03 0109 ○ 03 0110



03 0107  
PLASTİK BUTON  
TERMİNAL Lİ  
ÜST KORUMA ŞAPKALI

PUSH BUTTON SWITCH  
6,3mm TERMINAL  
WITHDAMP - PROOFCOVER



03 0108  
PLASTİK BUTON  
TERMİNAL Lİ  
ÜST VE ALT KORUMA ŞAPKALI

PUSH BUTTON SWITCH  
6,3mm TERMINAL  
WITHDAMP - PROOFCOVER  
WHOLE BODY