




01 0301  
SAĞ SOL ANAHTAR

CHANGEOVER SWITCH



01 0401  
ÇIT ÇIT ANAHTAR

ON/OFF TOGGLE SWITCH




01 0402  
SAĞ SOL ÇIT ÇIT ANAHTAR

ON/OFF/ON TOGGLE SWITCH




01 0501  
ÇİFT ÇEKME Lİ ANAHTAR

HEADLIGHT PUSH-PULL SWITCH



01 0502  
ÇİFT ÇEKME Lİ ANAHTAR  
20 A SİGORTALI

HEADLIGHT PUSH-PULL SWITCH  
(20 A FUSE)



03 0101  
PLASTİK BUTON  
KLEMENSLİ

PUSH-BUTTON SWITCH

● 03 0105 ○ 03 0106



03 0103  
PLASTİK BUTON  
KLEMENSLİ  
ÜST KORUMA ŞAPKALI

PUSH-BUTTON SWITCH  
WITHDAMP - PROOFCOVER

● 03 0111



03 0104  
PLASTİK BUTON  
KLEMENSLİ  
ÜST VE ALT KORUMA ŞAPKALI

PUSH-BUTTON SWITCH  
WITHDAMP - PROOFCOVER  
WHOLE BODY



03 0102  
PLASTİK BUTON  
TERMİNAL Lİ

PUSH BUTTON SWITCH  
6,3mm TERMINAL

● 03 0109 ○ 03 0110




03 0107  
PLASTİK BUTON  
TERMİNAL Lİ  
ÜST KORUMA ŞAPKALI

PUSH BUTTON SWITCH  
6,3mm TERMINAL  
WITHDAMP - PROOFCOVER



03 0108  
PLASTİK BUTON  
TERMİNAL Lİ  
ÜST VE ALT KORUMA ŞAPKALI

PUSH BUTTON SWITCH  
6,3mm TERMINAL  
WITHDAMP - PROOFCOVER  
WHOLE BODY



03 0201  
METAL BUTON

PUSH-BUTTON SWITCH METAL

● 03 0217 ● 03 0218

03 0203  
METAL BUTON  
ÜST KORUMA ŞAPKALI


PUSH-BUTTON SWITCH METAL  
WITHDAMP - PROOFCOVER

03 0202  
METAL BUTON  
GÜMÜŞ KONTAKLI

PUSH-BUTTON SWITCH METAL  
SILVER CONTACT

03 0207  
METAL BUTON  
GÜMÜŞ KONTAKLI  
ÜST KORUMA ŞAPKALI

PUSH-BUTTON SWITCH METAL  
SILVER CONTACT  
WITHDAMP - PROOFCOVER



03 0212  
METAL BUTON  
GÜMÜŞ KONTAKLI  
TERMİNALLİ

PUSH-BUTTON SWITCH METAL  
SILVER CONTACT

● 03 0215 ● 03 0216

03 0213  
METAL BUTON  
GÜMÜŞ KONTAKLI  
TERMİNALLİ

PUSH-BUTTON SWITCH METAL  
SILVER CONTACT  
WITHDAMP - PROOFCOVER

03 0305  
PİRİNÇ MARİN BUTON  
TERMİNALLİ

PUSH-BUTTON SWITCH BRASS

● 03 0307 ● 03 0306

03 0310  
PİRİNÇ MARİN BUTON  
TERMİNALLİ  
ÜST KORUMA ŞAPKALI

PUSH-BUTTON SWITCH BRASS  
WITHDAMP - PROOFCOVER



03 0301  
PİRİNÇ MARİN BUTON

PUSH-BUTTON SWITCH MARİN

● 03 0309 ● 03 0308

03 0302  
PİRİNÇ MARİN BUTON  
ÜST KORUMA ŞAPKALI

PUSH-BUTTON SWITCH BRASS  
WITHDAMP - PROOFCOVER

03 0303  
PİRİNÇ MARİN BUTON  
ÜST VE ALT KORUMA ŞAPKALI

PUSH-BUTTON SWITCH BRASS  
WITHDAMP - PROOFCOVER  
WHOLE BODY

03 0304  
BUTON KORUMA ŞAPKASI  
ÜST

RUBBER CAP

03 0204  
BUTON KORUMA ŞAPKASI  
ÜST

RUBBER CAP

03 0205  
BUTON KORUMA ŞAPKASI  
ALT

RUBBER CAP

03 0209  
MİDİ METAL BUTON  
KLEMENSLİ

MIDI PUSH-BUTTON SWITCH  
METAL

03 0210  
MİNİ METAL BUTON  
TERMİNALLİ

MINI PUSH-BUTTON SWITCH  
METAL