





Reference	Description	Housing Colour	Push Button Colour	Symbol	Symbol Colour	Type	Push Button Height / Type
03 0410	BELL SWITCH FOR HANDRAILS (SMOOTH)	GREY	RED	STOP	WHITE	VERTICAL	NORMAL
03 0440	BELL SWITCH FOR FLAT SURFACE (GRAINED)	GREY	RED	STOP	WHITE	VERTICAL	NORMAL
03 0470	BELL SWITCH FOR HANDRAILS (GRAINED)	GREY	RED	STOP	WHITE	VERTICAL	NORMAL
03 0430	BELL SWITCH FOR HANDRAILS (SMOOTH)	GREY	RED	STOP	WHITE	VERTICAL	HIGH
03 0432	BELL SWITCH FOR HANDRAILS (SMOOTH)	GREY	RED	STOP	WHITE	VERTICAL	NORMAL / BRAILLE
03 0510	BELL SWITCH FOR HANDRAILS (SMOOTH)	GREY	RED	STOP	WHITE	HORIZONTAL	NORMAL







Bell switch for flat surface



Grained

Smooth

Bell switch for 35 mm dia handrails
(Can be mounted 30 mm dia hanraile with adapter)





BELL SWITCHES FOR 30 mm AND 35 mm DIA HANDRAILS (SMOOTH) VERTICAL

Reference	Description	Housing Colour	Push Button Colour	Symbol	Symbol Colour	Type	Push Button Height / Type
03 0410	BELL SWITCH FOR HANDRAILS (SMOOTH)	GREY	RED	STOP	WHITE	VERTICAL	NORMAL
03 0411	BELL SWITCH FOR HANDRAILS (SMOOTH)	GREY	RED	Arrêt	WHITE	VERTICAL	NORMAL
03 0412	BELL SWITCH FOR HANDRAILS (SMOOTH)	GREY	BLUE	Pram	WHITE	VERTICAL	NORMAL
03 0413	BELL SWITCH FOR HANDRAILS (SMOOTH)	GREY	BLUE	Wheelchair	WHITE	VERTICAL	NORMAL
03 0414	BELL SWITCH FOR HANDRAILS (SMOOTH)	YELLOW	RED	STOP	WHITE	VERTICAL	NORMAL
03 0415	BELL SWITCH FOR HANDRAILS (SMOOTH)	YELLOW	RED	Arrêt	WHITE	VERTICAL	NORMAL
03 0416	BELL SWITCH FOR HANDRAILS (SMOOTH)	YELLOW	BLUE	Pram	WHITE	VERTICAL	NORMAL
03 0417	BELL SWITCH FOR HANDRAILS (SMOOTH)	YELLOW	BLUE	Wheelchair	WHITE	VERTICAL	NORMAL
03 0418	BELL SWITCH FOR HANDRAILS (SMOOTH)	GREY	BLUE	-	-	-	NORMAL
03 0419	BELL SWITCH FOR HANDRAILS (SMOOTH)	GREY	RED	-	-	-	NORMAL
03 0420	BELL SWITCH FOR HANDRAILS (SMOOTH)	YELLOW	BLUE	-	-	-	NORMAL
03 0421	BELL SWITCH FOR HANDRAILS (SMOOTH)	YELLOW	BLUE	STOP	WHITE	VERTICAL	NORMAL
03 0422	BELL SWITCH FOR HANDRAILS (SMOOTH)	YELLOW	RED	-	-	-	NORMAL
03 0423	BELL SWITCH FOR HANDRAILS (SMOOTH)	GREY	YELLOW	STOP	BLACK	VERTICAL	NORMAL
03 0424	BELL SWITCH FOR HANDRAILS (SMOOTH)	RED	YELLOW	STOP	BLACK	VERTICAL	NORMAL
03 0425	BELL SWITCH FOR HANDRAILS (SMOOTH)	BLUE	RED	STOP	WHITE	VERTICAL	NORMAL
03 0426	BELL SWITCH FOR HANDRAILS (SMOOTH)	GREEN	RED	STOP	WHITE	VERTICAL	NORMAL
03 0427	BELL SWITCH FOR HANDRAILS (SMOOTH)	GREEN	YELLOW	STOP	BLACK	VERTICAL	NORMAL
03 0428	BELL SWITCH FOR HANDRAILS (SMOOTH)	RED	BLUE	Pram	WHITE	VERTICAL	NORMAL
03 0429	BELL SWITCH FOR HANDRAILS (SMOOTH)	BLUE	YELLOW	STOP	BLACK	VERTICAL	NORMAL
03 0430	BELL SWITCH FOR HANDRAILS (SMOOTH)	GREY	RED	STOP	WHITE	VERTICAL	HIGH
03 0431	BELL SWITCH FOR HANDRAILS (SMOOTH)	YELLOW	RED	STOP	WHITE	VERTICAL	HIGH
03 0432	BELL SWITCH FOR HANDRAILS (SMOOTH)	GREY	RED	STOP	WHITE	VERTICAL	NORMAL / BRAILLE
03 0433	BELL SWITCH FOR HANDRAILS (SMOOTH)	YELLOW	RED	STOP	WHITE	VERTICAL	NORMAL / BRAILLE

BELL SWITCHES FOR FLAT SURFACES (GRAINED) VERTICAL

Reference	Description	Housing Colour	Push Button Colour	Symbol	Symbol Colour	Type	Push Button Height / Type
03 0440	BELL SWITCH FOR FLAT SURFACE (GRAINED)	GREY	RED	STOP	WHITE	VERTICAL	NORMAL
03 0441	BELL SWITCH FOR FLAT SURFACE (GRAINED)	GREY	RED	Arrêt	WHITE	VERTICAL	NORMAL
03 0442	BELL SWITCH FOR FLAT SURFACE (GRAINED)	GREY	BLUE	Pram	WHITE	VERTICAL	NORMAL
03 0443	BELL SWITCH FOR FLAT SURFACE (GRAINED)	GREY	BLUE	Wheelchair	WHITE	VERTICAL	NORMAL
03 0444	BELL SWITCH FOR FLAT SURFACE (GRAINED)	YELLOW	RED	STOP	WHITE	VERTICAL	NORMAL
03 0445	BELL SWITCH FOR FLAT SURFACE (GRAINED)	YELLOW	RED	Arrêt	WHITE	VERTICAL	NORMAL
03 0446	BELL SWITCH FOR FLAT SURFACE (GRAINED)	YELLOW	BLUE	Pram	WHITE	VERTICAL	NORMAL
03 0447	BELL SWITCH FOR FLAT SURFACE (GRAINED)	YELLOW	BLUE	Wheelchair	WHITE	VERTICAL	NORMAL
03 0448	BELL SWITCH FOR FLAT SURFACE (GRAINED)	GREY	BLUE	-	-	-	NORMAL
03 0449	BELL SWITCH FOR FLAT SURFACE (GRAINED)	GREY	RED	-	-	-	NORMAL
03 0450	BELL SWITCH FOR FLAT SURFACE (GRAINED)	YELLOW	BLUE	-	-	-	NORMAL
03 0451	BELL SWITCH FOR FLAT SURFACE (GRAINED)	YELLOW	BLUE	STOP	WHITE	VERTICAL	NORMAL
03 0452	BELL SWITCH FOR FLAT SURFACE (GRAINED)	YELLOW	RED	-	-	-	NORMAL
03 0453	BELL SWITCH FOR FLAT SURFACE (GRAINED)	GREY	YELLOW	STOP	BLACK	VERTICAL	NORMAL
03 0454	BELL SWITCH FOR FLAT SURFACE (GRAINED)	RED	YELLOW	STOP	BLACK	VERTICAL	NORMAL
03 0455	BELL SWITCH FOR FLAT SURFACE (GRAINED)	BLUE	RED	STOP	WHITE	VERTICAL	NORMAL
03 0456	BELL SWITCH FOR FLAT SURFACE (GRAINED)	GREEN	RED	STOP	WHITE	VERTICAL	NORMAL
03 0457	BELL SWITCH FOR FLAT SURFACE (GRAINED)	GREEN	YELLOW	STOP	BLACK	VERTICAL	NORMAL
03 0458	BELL SWITCH FOR FLAT SURFACE (GRAINED)	RED	BLUE	Pram	WHITE	VERTICAL	NORMAL
03 0459	BELL SWITCH FOR FLAT SURFACE (GRAINED)	BLUE	YELLOW	STOP	BLACK	VERTICAL	NORMAL
03 0460	BELL SWITCH FOR FLAT SURFACE (GRAINED)	GREY	RED	STOP	WHITE	VERTICAL	HIGH
03 0461	BELL SWITCH FOR FLAT SURFACE (GRAINED)	YELLOW	RED	STOP	WHITE	VERTICAL	HIGH
03 0462	BELL SWITCH FOR FLAT SURFACE (GRAINED)	GREY	RED	STOP	WHITE	VERTICAL	NORMAL / BRAILLE
03 0463	BELL SWITCH FOR FLAT SURFACE (GRAINED)	YELLOW	RED	STOP	WHITE	VERTICAL	NORMAL / BRAILLE

BELL SWITCHES FOR 30 mm AND 35 mm DIA HANDRAILS (GRAINED) VERTICAL

Reference	Description	Housing Colour	Push Button Colour	Symbol	Symbol Colour	Type	Push Button Height / Type
03 0470	BELL SWITCH FOR HANDRAILS (GRAINED)	GREY	RED	STOP	WHITE	VERTICAL	NORMAL
03 0471	BELL SWITCH FOR HANDRAILS (GRAINED)	GREY	RED	Arrêt	WHITE	VERTICAL	NORMAL
03 0472	BELL SWITCH FOR HANDRAILS (GRAINED)	GREY	BLUE	Pram	WHITE	VERTICAL	NORMAL
03 0473	BELL SWITCH FOR HANDRAILS (GRAINED)	GREY	BLUE	Wheelchair	WHITE	VERTICAL	NORMAL
03 0474	BELL SWITCH FOR HANDRAILS (GRAINED)	YELLOW	RED	STOP	WHITE	VERTICAL	NORMAL
03 0475	BELL SWITCH FOR HANDRAILS (GRAINED)	YELLOW	RED	Arrêt	WHITE	VERTICAL	NORMAL
03 0476	BELL SWITCH FOR HANDRAILS (GRAINED)	YELLOW	BLUE	Pram	WHITE	VERTICAL	NORMAL
03 0477	BELL SWITCH FOR HANDRAILS (GRAINED)	YELLOW	BLUE	Wheelchair	WHITE	VERTICAL	NORMAL
03 0478	BELL SWITCH FOR HANDRAILS (GRAINED)	GREY	RED	STOP	WHITE	VERTICAL	HIGH
03 0479	BELL SWITCH FOR HANDRAILS (GRAINED)	YELLOW	RED	STOP	WHITE	VERTICAL	HIGH
03 0480	BELL SWITCH FOR HANDRAILS (GRAINED)	GREY	RED	STOP	WHITE	VERTICAL	NORMAL / BRAILLE
03 0481	BELL SWITCH FOR HANDRAILS (GRAINED)	YELLOW	RED	STOP	WHITE	VERTICAL	NORMAL / BRAILLE

BELL SWITCHES FOR 30 mm AND 35 mm DIA HANDRAILS (SMOOTH) HORIZONTAL

Reference	Description	Housing Colour	Push Button Colour	Symbol	Symbol Colour	Type	Push Button Height / Type
03 0510	BELL SWITCH FOR HANDRAILS (SMOOTH)	GREY	RED	STOP	WHITE	HORIZONTAL	NORMAL
03 0511	BELL SWITCH FOR HANDRAILS (SMOOTH)	GREY	RED	Arrêt	WHITE	HORIZONTAL	NORMAL
03 0512	BELL SWITCH FOR HANDRAILS (SMOOTH)	GREY	BLUE	Pram	WHITE	HORIZONTAL	NORMAL
03 0513	BELL SWITCH FOR HANDRAILS (SMOOTH)	GREY	BLUE	Wheelchair	WHITE	HORIZONTAL	NORMAL
03 0514	BELL SWITCH FOR HANDRAILS (SMOOTH)	YELLOW	RED	STOP	WHITE	HORIZONTAL	NORMAL
03 0515	BELL SWITCH FOR HANDRAILS (SMOOTH)	YELLOW	RED	Arrêt	WHITE	HORIZONTAL	NORMAL
03 0516	BELL SWITCH FOR HANDRAILS (SMOOTH)	YELLOW	BLUE	Pram	WHITE	HORIZONTAL	NORMAL
03 0517	BELL SWITCH FOR HANDRAILS (SMOOTH)	YELLOW	BLUE	Wheelchair	WHITE	HORIZONTAL	NORMAL
05 0518	BELL SWITCH FOR HANDRAILS (SMOOTH)	YELLOW	BLUE	STOP	WHITE	HORIZONTAL	NORMAL
03 0519	BELL SWITCH FOR HANDRAILS (SMOOTH)	GREY	YELLOW	STOP	BLACK	HORIZONTAL	NORMAL
03 0520	BELL SWITCH FOR HANDRAILS (SMOOTH)	RED	YELLOW	STOP	BLACK	HORIZONTAL	NORMAL
03 0521	BELL SWITCH FOR HANDRAILS (SMOOTH)	BLUE	RED	STOP	WHITE	HORIZONTAL	NORMAL
03 0522	BELL SWITCH FOR HANDRAILS (SMOOTH)	GREEN	RED	STOP	WHITE	HORIZONTAL	NORMAL
03 0523	BELL SWITCH FOR HANDRAILS (SMOOTH)	GREEN	YELLOW	STOP	BLACK	HORIZONTAL	NORMAL
03 0524	BELL SWITCH FOR HANDRAILS (SMOOTH)	RED	BLUE	Pram	WHITE	HORIZONTAL	NORMAL
03 0525	BELL SWITCH FOR HANDRAILS (SMOOTH)	BLUE	YELLOW	STOP	BLACK	HORIZONTAL	NORMAL
03 0526	BELL SWITCH FOR HANDRAILS (SMOOTH)	GREY	RED	STOP	WHITE	HORIZONTAL	HIGH
03 0527	BELL SWITCH FOR HANDRAILS (SMOOTH)	YELLOW	RED	STOP	WHITE	HORIZONTAL	HIGH
03 0528	BELL SWITCH FOR HANDRAILS (SMOOTH)	GREY	RED	STOP	WHITE	HORIZONTAL	NORMAL / BRAILLE
03 0529	BELL SWITCH FOR HANDRAILS (SMOOTH)	YELLOW	RED	STOP	WHITE	HORIZONTAL	NORMAL / BRAILLE